







<b>A1</b>	Feuerungsautomat	Coffret de contrôle	Programmatore di comando	Bedienings en veiligheidskoffer	Control and safety unit
<b>A4</b>	Display	Afficheur	Visualizzatore	Uitlezing	Display
<b>A5</b>	Drehzahlregler	Variateur	Variatore	Frequentieregelaar	Variable speed controller
<b>B1</b>	Ionisationssonde	Sonde de ionisation	Sonda d'ionizzazione	Ionisatie-sensor	Ionisation sensor
<b>B10</b>	Messbrücke	Pont de mesure	Ponte di misura	Meetbrug	Current bridge
<b>F4</b>	Gasdruckwaechter min.	Manostat gaz mini	Pressostato gas min.	Gaspressostaat min.	Min. gas pressure switch
<b>F6</b>	Luftdruckwächter	Manostat d'air	Pressostato aria	Luchtpressostaat	Air pressure switch
<b>K1</b>	Kontaktschalter des Ventilators	Contacteur du ventilateur	Contattore del ventilatore	Contacteur van ventilator	Fan unit contactor
<b>M1</b>	Brennermotor	Moteur du brûleur	Motore del bruciatore	Brandermotor	Burner motor
<b>T2</b>	Zündtrafo	Transformateur d'allumage	Trasformatore d'accensione	Ontstekingstransformator	Ignition transformer
<b>Y10</b>	Stellantrieb	Servomoteur	Servomotore	Servomotor	Servomotor
<b>Y12</b>	Gasventiligasseitig	Vanne gaz de sécurité	Valvola sicurezza gas	Veiligheidsventiel gas	Safety gas valve
<b>Y13</b>	Gasventil Brennerseitig	Vanne gaz principale	Valvola principale gas	Hoofdafsluiter gas	Gas valve burner side
<b>101</b>	Ventilator	Ventilateur	Ventilatore	Ventilator	Blower
<b>103</b>	Luftklappe	Volet d'air	Serranda aria	Luchtklep	Air flap
<b>104</b>	Druckregler	Régulateur de pression	Regolatore della pressione	Drukregelaar	Pressure regulator
<b>106</b>	Filter	Filtre	Filtro	Filter	Filter
<b>108</b>	Handventil	Vanne manuelle	Valvola manuale	Handventiel	Manual valve
<b>110</b>	Gasinjektor	Injecteur gaz	Ugello gas	Gasinjector	Gas injector
<b>113</b>	Ansauggitter	Grille d'aspiration	Scatola dell'aria	Luchthuis	Air box protection
<b>119</b>	Messnippel	Prise pression	Presa pressione	Meetnippel	Pressure take-off